



Getting Started with the EVM Application

The supported operating systems for the EVM application are Windows XP and Windows 7 with administrative rights.

Windows XP instructions

1. Run file: [\USB driver\CDM20814_Setup.exe](#).
2. Connect the USB cable between the computer and the EVM.
3. Install the application: [\Application\setup.exe](#).
4. After installation completes, click the "Connect" button at the top.

Windows 7 instructions

1. Make sure to be logged in as an administrator.
2. Go to folder [\USB driver\](#).
3. Right-click [CDM20814_Setup.exe](#) and select Properties. Go to the Compatibility tab, check "Run this program in compatibility mode for", select "Windows XP (Service Pack 2)", OK.
4. Now run [CDM20814_Setup.exe](#). Click "Yes" to the pop-up window.
5. Connect the USB cable between the computer and the EVM.
6. Install the application: [\Application\setup.exe](#).
7. After installation completes, click the "Connect" button at the top.

Note: if there's a COM Port pop-up warning, the port number needs to be changed in Device Manager. To do this, open Start/Control Panel/System, [XP: Hardware tab,] Device Manager button, expand Ports, double click USB Serial Port, Port Settings tab, Advanced button, select COM4 from the dropdown menu, OK, OK. Then rerun the application.

For detailed EVM usage instructions, download the User's Guide from the device EVM webpage.